

PL-3000 PlasmaLift

Programming Show Position

- 1.) Press 'UP' button. Unit should cycle to stored position.
- 2.) Press and hold 'STOP' button for 10 seconds – unit is now in manual mode.
- 3.) Press 'DOWN' button momentarily – unit will travel down. When unit reaches desired show position press 'STOP' button momentarily.
- 4.) Press and hold 'STOP' button for 10 seconds.
- 5.) Press 'UP' button momentarily – unit will travel to upper position.
- 6.) Unit is now programmed – press 'DOWN' button to verify – unit should travel down to show position.